

# INSTALLATION GUIDELINES

## Screening Booth Ceiling Feed

Ceiling feed harness has already been connected and conduit is hanging down from ceiling. Choose which side of the booth you would like to install the ceiling feed. Position that side of the Screening Booth below the hanging conduit.

**STEP 1:** Place the ceiling feed post(A) with long side against the wall and short side against the aluminum frame.

**STEP 2:** Assemble the post support(B) using the screw(C) and spacer(D). They are fastened to the support using one of the open holes. "Spacer Image" below shows which hole to use.

**STEP 3:** Fish the electrical conduit(F) through work surface grommet(G).

**STEP 4:** Remove double side tape backing(E) on the post support(B). Lift up the post(A) and slide the post support(B) between work surface and post(A). The Spacer(D) must push the post against the wall and aluminum frame.

**STEP 5:** Flex the Ceiling Feed Bezel(I) so that it fits over the Post(A). Secure the Bezel(I) to the ceiling with 4 screws(J).

**STEP 6:** Snap in the Ceiling Feed Cover(H) to the Post(A).

